




LIGHT KIT CETUS – DIMMING FUNCTION

USE THE DIMMING FUNCTION FOR YOUR LIGHT KIT

The remote control is pre-set for ON/OFF for the light kit. To activate the dimming function you need to change the Dip-switch (434) to the far right (see the arrow) from ON-mode to I-mode. Just press the switch upwards. The DIP switches for the transmitter (remote hand piece) are located in the battery compartment of the transmitter.

This light kit is only to be used for Cetus ceiling fan.




BELYSNING CETUS – DIMNINGSFUNKTION

ANVÄNDA DIMNINGSFUNKTIONEN FÖR DIN FLÄKTBELYSNING

Fjärrkontrollen levereras förinställd för att belysningen ska användas ON/OFF. För att aktivera dimningsfunktionen på fläktbelysningen behöver du ändra Dip-switchen (434) längst till höger (se pilen) från ON-läge till I-läge. Det är bara till att trycka upp Dip-switchen. DIP-switcharna för sändaren (fjärrkontrollen) finns inne i batterifacket på sändaren.

Denna belysning får endast användas till takfläkten Cetus



BELEUCHTUNG CETUS- DIMMEN

DIMMEN DER BELEUCHTUNG

Die Fernbedienung ist auf ON/OFF für die Beleuchtung vorinstalliert. Um die Beleuchtung dimmen zu können, muss der DIP Switch (434) ganz rechts (sehen Sie den Pfeil) von ON-Modus bis I-Modus geändert werden. Sie drücken nur den Knopf nach oben. Die DIP Switches sind neben der Batterie der Sender (Fernbedienung).

Diese Beleuchtung ist nur für Cetus geeignet.

